

## HTC VIVE BUSINESS+ ULTIMATE



Cena celkem:	<b>17 476 Kč</b> <b>(bez DPH: 14 443 Kč)</b>
Běžná cena:	<b>19 224 Kč</b>
Ušetříte:	<b>1 748 Kč</b>
Kód zboží:	VRHTC0029
Part No.:	69HVABMSH36M01-00
Záruka:	12 měs. IČO / 24 měs. EU
Stav:	Nové zboží

## Popis

### HTC Business+ Ultimate

**HTC VIVE Business+** je řešení softwaru a služeb pro správu **HTC VIVE Focus 3**. Přizpůsobte si samostatné náhlavní soupravy VR tak, aby vyhovovaly vašim firemním potřebám. Licence je platná 3 roky. Verze Ultimate nabízí **5 GB cloudového úložiště** pro sdílení map, vzdálenou instalaci obsahu a distribuci do skupin zařízení po síti (soubory .apk a .obb) či vlastní animace při spouštění zařízení.

Licence je určena **pro komerční použití**. VIVE Business+ nepodporuje licencovaný obsah z VIVE Business AppStore nebo VIVEPORT.

#### Správa zařízení

Rychle a snadno zaregistrujte náhlavní soupravy pomocí naskenování QR kódu, aktualizujte nastavení/konfigurace hardwaru a spravujte svá zařízení na dálku.

#### Správa obsahu

Nahrávejte vlastní obsah, spravujte knihovnu a instalujte aplikace do všech náhlavních souprav VIVE Focus 3 odkudkoli.

#### Vzdálená správa obsahu

Přístup k obsahu a jeho správa v rámci organizace není nikdy jednoduchá. VIVE Business+ umožňuje vzdáleně nahrávat a spravovat všechny aplikace a verze v cloudu. Nahrávejte vlastní soubory .apk a .obb. Centrálně spravujte a spolehlivě škálujte svá nasazení.

#### Správa uživatelů

Přidejte uživatele a nastavte oprávnění pro role správce, editora či diváka. Vytvořte více organizací pro samostatné týmy. Udržujte kontrolu nad všemi na jednom místě.

#### Správa skupin

Vytvořte skupinu pro svá zařízení a rychle a efektivně nasazujte aktualizace nebo aplikujte přizpůsobitelná nastavení.

Změňte skupinová nastavení ROM, aplikací, map a zobrazte okamžité aktualizace ve všech seskupených zařízeních.

### Pokročilé funkce

Poskytněte uživatelům lepší zážitky díky přizpůsobitelným možnostem uživatelského rozhraní a režimům sledování VIVE Location-Based Software Suite (LBSS).

### Vzdálené monitorování a ovládání zařízení

Sledujte stav baterie náhlavní soupravy a ovladače, stav Wi-Fi a další důležité údaje. Mějte lepší kontrolu nad svými zařízeními odkudkoli. Vzdáleně restartujte, vypínejte a resetujte náhlavní soupravy do továrního nastavení.

### Funkce a vlastnosti:

## VIVE BUSINESS+ FEATURES

	FEATURES	DESCRIPTION	STANDARD	PRO	ULTIMATE	NOTES
<b>User Admin</b>	Overview Dashboard	Organization enrolled device lists, available seats, expiration... etc.	•	•	•	
	Role-based User Management	Admin, Editors, Viewer roles	•	•	•	
	Member Management	Add, delete, and assign user accounts to organizations	•	•	•	
	Permission Management	Admin privileges for modifying user permissions	•	•	•	
	Cloud Storage	Storage for configurations, maps, and custom content files for remote installation		1GB	5GB	per device
	Code Redemption	Organization creation and seats redemption	•	•	•	
<b>Device Management</b>	<b>NEW</b> QR Code Enrollment	QR-Code initiated device setup and enrollment for the VIVE Focus 3	•	•	•	
	<b>NEW</b> Standard Device Status	Device battery level, sync time... etc. dashboard	•	•	•	
	<b>NEW</b> Batch Configuration	Batch configuration for device groups	•	•	•	
	<b>NEW</b> Device Groups	Device grouping and group management features	•	•	•	
	<b>NEW</b> Issue Report/Tracking	Device logging on VBMS and issue ticketing	•	•	•	
	<b>NEW</b> Remote Device Management	Remote device reboot, shutdown, and wipe... etc.	•	•	•	
	<b>NEW</b> Advanced Device Status	Device storage, content list... etc.		•	•	
	<b>NEW</b> Remote Content Management & Distribution	Remote content installation and distribution to device groups over network (APK and OBB files)			•	
	Customized Boot Screen	Custom device boot up animation		•		
<b>System Updates</b>	Offline Device ROM Update	Update to ROM manually using SD card	•	•	•	
	<b>NEW</b> Device management and FOTA Assignment	System version management, supporting device groups and support force updates.	•	•	•	
	<b>NEW</b> ROM Update via SD Card	Automatically update to specific ROM version directly by SD card			•	
<b>Advanced Tracking Features (LBSS)</b>	Visual Odometry (VO) Tracking Mode	Access to VO Mode	<b>NEW</b> •	•	•	
	Immersive Customization	Disable default system UI elements (refer to batch configuration)		•	•	
	LBE Configurations	Tracking mode selection and corresponding settings (refer to batch configuration)		•	•	
	Map Sharing	Map sharing between HMDs for alignment		•	•	
	Advanced Tracking Features	MBSL, MBSA, Drift Prevention Mode		•	•	

## BATCH CONFIGURATION SETTINGS

	FEATURES	STANDARD	PRO	ULTIMATE
<b>General</b>	System language	•	•	•
	Timezone	•	•	•
	Network time enabling	•	•	•
	Double click to show pass through	•	•	•
	Allow BT	•	•	•
	Hand tracking enable/disable	•	•	•
	Show/hide Vive Sync	•	•	•
<b>Wi-Fi settings</b>	Wi-Fi certificate	•	•	•
	Wi-Fi setup	•	•	•
	VPN certificate	•	•	•
	VPN setup	•	•	•
<b>Device settings</b>	Boundary color	•	•	•
	Boundary transparent	•	•	•
	Show pass through automatically when out of boundary	•	•	•
	Always show floor bound	•	•	•
	Power frequency	•	•	•
	Allow recording and casting	•	•	•
	USB debugging	•	•	•
	Period to enter sleep mode	•	•	•
<b>Tracking Features</b>	Hide pre-loaded content -> VIVE Sync	•	•	•
	Hide pre-loaded content -> Firefox Reality	•	•	•
	Hide pre-loaded content -> VIVE Business Streaming	•	•	•
<b>Kiosk mode</b>	Kiosk mod - select content	•	•	•
	Kiosk mod - password	•	•	•
	Kiosk mod - Activate kiosk mode	•	•	•
	Kiosk mod - network mode (any, pre-set, offline)	•	•	•
	Kiosk mod - interaction mode	•	•	•
	Kiosk mod - Show/hide tutorial/opening video/wearing guide	•	•	•
	Kiosk mod - Allow BT connection	•	•	•
	Kiosk mod - Allow casting	•	•	•
	Kiosk mod - Allow screenshot and recording	•	•	•
	Kiosk mod - Allow USB translation	•	•	•
<b>UI Related</b>	Disable controller pairing and the UI after initial setup		•	•
	Disable Vive menu on the R controller and HMD button		•	•
	Disable Function Menu		•	•
	Disable USB connection dialog		•	•
	Disable Volume adjustment Bar		•	•
	to consent volume warning dialog by volume up key		•	•
	Disable Volume safety notification		•	•
	Disable low battery notification		•	•
	Disable IPD adjustment overlay		•	•
	Skip OOB		•	•
	Customized boot logo		•	•
	Customized boot animation		•	•
	Customized boot duration (logo & animation)		•	•
	To Hide tabs from MainNav		•	•
	enable System firmware update management		•	•
Disable content transition		•	•	
Disable shutdown screen image		•	•	
<b>HW Keys</b>	enable Lost tracking event integration		•	•
	Disable lost tracking animation		•	•
	Disable lost tracking black background		•	•
	Marker-based location sharing (VO mode only)		•	•
	enable Marker-based drift prevention		•	•
	Disable Reset View function		•	•
	Support 1 controller 1 wrist tracker		•	•
	Enable hand tracking as default		•	•
	Disable VIVE button on right controller		•	•
	Disable volume up/down buttons on HMD		•	•
Disable Headset button on HMD		•	•	
Disable hand gesture "palm pinch"		•	•	
Pop up Vive menu by single click headset button		•	•	
enable 2 ways communication on wrist tracker		•	•	

# BUSINESS BUILDING BLOCKS

## BUSINESS WARRANTY AND SERVICES

### Business Warranty & Support 2 or 3 years

Enterprise-grade support and services to protect your investment.

Two (or 3-years ) warranty, phone support and expedited repair



### VIVE Advanced Device Management System –services

#### Standard Tier Included with BWS

New VIVE Advanced Device Management System features

- QR Code enrolment
- NEW Device Status
- NEW Group Management
- XR Elite 3<sup>rd</sup> Party MDM use



#### Pro Tier Optional (F3 only)

- Remote Device Management
- Advanced device status
- Focus 3 Location Based Software Suite



#### Ultimate Tier Coming Later (F3 only)

- Content management and delivery with more content storage
- Advanced features like deep API integration

